

## Read This First! Important Safety Instructions.

**READ AND HEED IMPORTANT  
SAFETY WARNING ON POWER  
SUPPLY.**

**CAUTION:**

**RISK OF ELECTRIC SHOCK**  
**DRY LOCATION USE ONLY**

ATTENTION:

POUR UTILISATION A  
L'INTÉRIEUR SEULEMENT

**IMPORTANT.**



The lightning flash with arrowhead, within an equilateral triangle, is intended to alert the user of the presence of uninsulated “dangerous voltage” within a product’s enclosure that may be of sufficient magnitude to constitute the risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user of the presence of important operating and maintenance (servicing) instructions in the literature accompanying this product.

**Read Instructions.** All safety and operating instructions should be read before your ZVOX™ Console is operated.

**Keep These Instructions.** Safety instructions and operating instructions should be kept for future reference.

**Heed All Warnings.** All warnings on the product or in the operating instructions should be followed.

**Follow Instructions.** Operate your ZVOX Console in accordance with the instructions.



**Do Not Use Near Water.** Do not use your ZVOX Console near water, such as a bathtub, sink, swimming pool or wet basement. To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture. To avoid dripping and splashing, no objects filled with liquids, such as vases, should be placed on your ZVOX Console.



**Object Entry.** Never use probes of any kind to reach into the Console as they may touch voltage points or short parts that could result in a fire or electric shock.



**Stable Placement.** Do not place the Console on an unstable cart, stand, bracket or table. The Console may fall, causing serious injury to a child or adult and serious damage to the product.

**Ventilation.** The control panel and bass port of your ZVOX Console provide ventilation to ensure reliable operation of the system and to prevent it from over-heating. These areas must not be blocked or covered. Do not allow a soft surface such as carpet, bedding or a sofa to block the bass port or cover the control panel. The Console should not be placed in a built-in installation such as a bookcase or a rack unless proper ventilation is provided.

**Heat.** Your Console should be placed away from radiators, stoves, heat vents or other heat sources.



**Do Not Abuse The Power Cord.** Install the Console where no one can step on or trip on the power cord. Never yank to disconnect the cord from an outlet. Keep the cord away from heated surfaces. Do not pull the cord around sharp edges or corners. Do not allow the cord to hang over the edge of a table or counter.

**Power Supply.** Do not use a power supply with a higher voltage rating than the unit supplied with your ZVOX Console.

**Power Sources.** The Console should be operated only with a 60HZ 120VAC power source.

**Do Not Overload Outlets.** Don't overload your wall outlets or power

strip. This can result in the risk of fire or electric shock.

**Damage Requiring Service.** Unplug your Console and refer servicing to an authorized service center when the following conditions occur:

- When the power supply cord or plug is damaged or frayed.
- If liquid is spilled into the unit.
- If the Console has been exposed to rain or water.
- If the Console does not work normally by following the operating instructions.
- If the unit has been dropped or physically damaged.
- If the unit exhibits a distinct change in performance.

**Lightning.** Unplug your Console during a lightning storm, or when it is left unattended and unused for long periods of time. This will prevent damage due to lightning and power line surges.



**Unplug Before Cleaning.** Unplug your ZVOX Console from wall outlet or other power source before cleaning. Use a damp cloth for cleaning. Do not use solvents or chemical cleaning agents.

**Attachments.** Do not use any adapters or attachments not recommended by ZVOX Audio, as they may cause hazards.

**Servicing.** Do not attempt to service this product yourself. Do not remove the cover. Refer all servicing to qualified service personnel.

**Replacement Parts.** Do not allow anyone to use replacement parts other than those recommended by the manufacturer. Unauthorized substitutions may result in fire, electric shock or other hazards.

**Safety Check.** Upon completion of any service or repair to this product, ask the service technician to perform safety checks to determine whether the product is in proper operating condition.

ZVOX Audio, LLC  
59 Thomas Road  
Swampscott, MA 01907 USA  
info@zvoxaudio.com  
www.zvoxaudio.com



1. Unpack Console, AC power supply and 2 connecting cords – one with “RCA” plugs, and one with a “mini plug” connector.




2. Place console facing listening area, leaving 2” of space behind it for bass port. If using the Console with a TV, try to align the Console with the center of the screen.




3. Connect AC power supply cord to “Power” port on console, then plug into AC outlet.

 DO NOT plug cord into AC outlet before it is connected to “Power” port of Console.



4. Examine audio outputs or headphone jack of your TV, PC, CD/MP3 player, game console or radio to determine if it uses a “mini jack” or “RCA” connectors. Choose and connect appropriate cord.



5. **For TV connection only: All other devices, skip to step 6.** If connected to a TV audio output, push the “MENU” button on your remote control, then choose “AUDIO” -- and navigate through the menu options to choose “SPEAKER: OFF” and “AUDIO OUT: VARIABLE” (sometimes called “AOV” on a TV’s menu).

If your TV’s audio output can’t be switched to “VARIABLE,” or if it doesn’t have audio out jacks, connect the ZVOX Console to the TV’s headphone jack. Your TV’s volume control will then control the volume of the ZVOX Console.

If your TV doesn’t have a headphone jack, or variable audio outputs, then you can connect your ZVOX Console to the variable audio output of your cable box. But other devices (VCR, DVD player) will not play through the ZVOX Console, unless they are connected through your cable box. If no variable audio output connection is available, you must vary the volume using the volume control on the back panel of the ZVOX Console.



6. **IMPORTANT:** Turn down volume control on back panel of ZVOX Console to about the “9 o’clock” position.



7. Plug other end of audio connecting cable into “Input 1” plug on back of ZVOX Console.



8. Turn Power switch to “On.” Then activate TV, PC, CD/ MP3 player, radio or other audio device.



9. With volume control of TV/PC/Audio Device set at about 75% of maximum, turn up the volume of ZVOX Console all the way, or until audible distortion occurs. If distortion occurs, turn ZVOX volume control down until distortion goes away.

10. Listen and enjoy. When you’re finished, simply turn off your TV/audio source. Use the volume control or remote control of your TV/ audio source to vary the volume to suit your taste.

After 3 minutes without receiving an audio signal, your ZVOX Console will automatically shut down its amplifier. When you turn on your TV/audio source, the ZVOX Console will automatically turn itself on again. The auto turn-on function takes 1-2 seconds. Note: If auto shutdown occurs when listening at very low volume levels, you may need to adjust the ZVOX volume control DOWN somewhat, and turn the volume of your TV/audio source UP. This will assure a strong enough signal to prevent inadvertent shutdown.

Questions? See the “User Guide” section of our web site: [www.zvoxaudio.com](http://www.zvoxaudio.com).



**A few opportunities for fine-tuning.**

1. If your TV, CD player, PC or other audio source plays too loudly, even with its volume control turned only part way up, you may want to reduce the volume level on the back of your ZVOX Console (“Main Volume”).

2. If you hear a consistent “hiss” or hum from your ZVOX Console, try turning UP the volume of your TV or other audio source, and then set the ZVOX volume level LOWER. If your TV is connected to a cable box or satellite receiver, try turning its volume control UP – so that when you switch from your cable box to your DVD player, they play at about the same level. As a rule of thumb, try setting each device at about 75-90% of its maximum volume level -- then turn the ZVOX Console’s volume control up as far as it will go without distorting. After that, make all volume adjustments from your TV or other audio source.

In some circumstances, you will hear excess hiss if your TV/audio source is turned up TOO high. If this happens, try adjusting the TV/ audio source sound level DOWN and turn the ZVOX Console volume UP.

Please keep in mind that your ZVOX Console is a highly accurate audio system that may reveal noise or distortion that other speakers did not reproduce. This is not the fault of the ZVOX Console, which is simply reproducing the signal it receives.

3. The PhaseCue control adjusts the size of the perceived “sound stage.” Feel free to adjust it when playing different kinds of audio. Some people prefer slightly more, or slightly

less PhaseCue effect. The recommended setting is “11-3 o’clock” on the control. If the sound is overly bright (too much treble), try turning down the PhaseCue control.

3. If you are placing the Sound Console on the floor, in a corner, or near the ceiling, you may find that it produces too much bass – resulting in a “muddy” sound. If this happens, turn down the subwoofer level control until the “muddy” or “boomy” sound goes away.



- “Input 1” jack is for connecting audio connector cable from TV, PC or other audio source.
- “Output (Input 2)” jack is for connection of optional powered subwoofer, and also acts as a second, mixing input. It will only act as an input if another device is already connected to the “Input 1” jack.
- “Main Volume” is a “set and forget” volume control. After initial setup, you shouldn’t need to adjust it.
- “Phase Cue” adjusts the size of the sound stage. Proper setting for most uses: “11-3 o’clock.”
- “Subwoofer Level” adjusts bass output.